

REPLACEMENT PARTS GUIDE

6B Series - 954 (511911 -), 1204 (511432 -), 1354 (510198 -), 1404 Tractors (China Edition)




CAB

RECIRCULATION AIR FILTER
[RE195491](#) (954, 1204, 1354)
[SU41628](#) (1204)
[SU41769](#)

Clean after every 250 hours and annually. change as required.

FRESH AIR FILTER
[RE198488](#) (954, 1204, 1354)

Service after every 250 hours. change as required.



HYDRAULIC



OIL FILTER
[SJ11792](#) (954, 1204, 1354)
[RE172178](#) (1404)

Replace after first 100 hours then after every 500 hours.

(Click here for [capacity](#))

ENGINE

WATER SEPARATOR
[N378886](#) (1204)

Replace after every 500 hours.



ENGINE

OIL FILTER
[RE504836](#) (954, 1204, 1354)

Change after first 100 hours and then every 500 hours. If PLUS-50 oil and a John Deere filter are not used, lower this service interval to 250 hours.

(Click here for [capacity](#))



PRIMARY FUEL FILTER
[RE546336](#) (954, 1204, 1354)

FINAL FUEL FILTER
[RE544394](#) (954, 1204, 1354)

Replace after every 500 hours.



PRIMARY AIR FILTER
[AL172780](#) (954, 1204, 1354)
[RE171235](#) (1404)

SECONDARY AIR FILTER
[AL150288](#) (954, 1204, 1354)
[RE171236](#) (1404)

Replace after every 1000 hours or annually whichever occurs first. Change as required.



CAPACITIES

6B Series - 954 (511911 -), 1204 (511432 -), 1354 (510198 -), 1404 Tractors (China Edition)



CAPACITIES (Approximate):

Fuel Tank:

954.....	150 L (39.62 gal)
1204, 1354.....	220 L (58.12 gal)
1404	
Four Cylinders.....	210 L (55.48 gal)
Six Cylinders.....	255 L (67.36 gal)

Crankcase including Filter Change:

Plus-50™ II

954, 1204, 1354.....	15 L (3.96 gal)
1404	
Four Cylinders.....	15 L (3.96 gal)
Six Cylinders.....	17 L (4.49 gal)

Cooling System:

Cool-Gard™ II

954, 1204, 1354.....	18 L (4.76 gal)
1404	
Four Cylinders.....	18 L (4.76 gal)
Six Cylinders.....	23 L (6.08 gal)

Transmission and Hydraulic System:

Hy-Gard™

.....	60 L (15.65 gal)
-------	------------------

Mechanical Front Wheel Drive (MFWD) Axle Housing:

Hy-Gard™

954.....	5.5 L (1.45 gal)
1204, 1354, 1404.....	5 L (1.32 gal)

Mechanical Front Wheel Drive (MFWD) Hubs (Each):

Hy-Gard™

954.....	1.1 L (0.29gal)
1204, 1354, 1404.....	0.8 L (0.21 gal)

*Parts located in front with respect to model image.

REPLACEMENT PARTS GUIDE

6B Series - 954 (511911 -), 1204 (511432 -), 1354 (510198 -), 1404 Tractors (China Edition)



ENGINE




BRAKE DISK

[AL160176](#) (1204,1354,1404)

(Multiple Disk, self lock)

[SU34458](#) (ALL) (Hand Brakes)

[NF501851](#)(1240) (MFWD)



CLUTCH DISK

[RE222670](#) (954) (Low Capacity)

[YZ91139](#) (ALL) (High Capacity)



BATTERY

[3BM2014](#) (1404)

[SJ19484](#) (1204,1354)

[SJ36671](#) (954)



ALTERNATOR

[SJ24309](#) (90A)(1204,1354)



CAB

SEAT

[SJ10749](#) (1404)

[SJ20422](#) (954,1204,1354) (With Arm rest)

[SJ20423](#) (954,1204,1354) (Without Arm rest)

[SJ29370](#) (954,1204,1354) (Bottom)

[SJ29371](#) (954,1204,1354) (Back)



ENGINE

FAN DRIVE BELT

[L153280](#) (1204,1354) (120 HP, With out AC)

[L111600](#) (1204,1354) (95 HP, With AC)

[L111601](#) (954) (90 HP, With AC)

[L114488](#) (954) (90 HP, Without AC)

[L114293](#) (954) (Without AC)

[L114290](#) (954) (Without AC,With AirPump)



AXLE

TIE ROD

[AL204774](#) (1204,1354,1404) (MFWD,Basic)

[AL226443](#) (1204) (MFWD,LitePaddy)

[AL225626](#) (1204) (MFWD,Lite Dry)

[AL227349](#) (954)



JOHN DEERE
Genuine Parts and Service

CLICK PART NUMBER TO BUY