

REPLACEMENT PARTS GUIDE

X147R 100 Series Tractor

ELECTRICAL



KEY
[GY20680](#)



HEAD LIGHT BULB
[AD2062R](#) (27 W)



IGNITION SWITCH
[GY20074](#)



BATTERY
[TY25221B](#) (12 V) (FOR CANADA AND USA)
[MCYP340PF](#) (12 V) (NOT FOR CANADA AND USA)

FUEL & AIR



FILLER CAP
[GX22166](#)



MUFFLER
[AUC15763](#)



ENGINE



SPARK PLUG
[MIU11020](#)
Yearly / Every 50 Hrs.



OIL FILTER
[AM125424](#)
Yearly / Every 50 Hrs.



ENGINE OIL
[TY22029](#) (Turf-Gard 10W-30)-1.9 L (2qt)
Yearly / Every 50 Hrs.



AIR FILTER
[MIU14395](#) (A/C CARTRIDGE)
Yearly / Every 50 Hrs.



JOHN DEERE MULTI-PURPOSE HD LITHIUM COMPLEX GREASE
[TY24416](#)
GREASE GUN
[TY26518](#)
Change As Required.



FUEL FILTER
[AM116304](#)
Yearly / Every 50 Hrs.



HOME MAINTENANCE KIT
[AUC17067](#) (FOR EUROPE)



TRACTION BELT
[GX23798](#) (LGTH = 12771.81 mm,
TK = 8.89 mm, WIDTH = 13.5 mm)
(TRACTION DRIVE)


REPLACEMENT PARTS GUIDE

X147R With 36 inch Deck


MOWER BLADE

 [GX24566](#) (LH)

[GX24567](#) (RH)



V BELT

 [GX25209](#) (LGTH = 3169 mm, TK = 14.7 mm, WIDTH = 16 mm)