

REPLACEMENT PARTS GUIDE

2R Series - 2026R Compact Utility Tractor



ENGINE

OIL FILTER

[M806418](#)

Replace every 200 hours and annually if less than 200 hours of operation



1

INLINE FUEL FILTER

[AM116304](#)

Replace every 400 hours and annually.



2

FUEL FILTER

[M801101](#) USE WITH [MIA883607](#)

[MIU804763](#) USE WITH [MIA884997](#)

Replace after every 400 hours or Annually, Whichever occurs first.



3

TRANSMISSION

HYDRAULIC FILTER

[LVA16054](#)

Replace after first 50 hours and every 200 hours.



4

PRIMARY AIR FILTER

[M113621](#) (-200380), [LVU34503](#) (200381 -)

SECONDARY AIR FILTER

[M123378](#) (- 200380), [LVU34504](#) (200381 -)

Replace every 400 hours and as required. Check and service every 10 hours/daily, every 200 hours and annually.



5

CLICK PART NUMBER TO BUY

*See operator's manual for additional details.

CAPACITIES

2R Series - 2026R Compact Utility Tractor

CAPACITIES (Approximate):

Fuel Tank:
..... 20.4 L (5.3 gal)

Cooling System:
Cool-Gard™ II
..... 3.7 L (0.8 gal)

Crankcase with Filter:
Plus-50™
..... 2.7 L (0.6gal)

Transmission and Hydraulic system
Hy-Gard™
..... 14.4 L (3.8 gal)

Front Axle:
Hy-Gard™
..... 2.8 L (0.6 gal)

REPLACEMENT PARTS GUIDE

2R Series - 2026R Compact Utility Tractor




ENGINE



BRAKE DISK
[LVA16465](#) (BRAKE)

1



CLUTCH DISK
[LVA15954](#) (PTO CLUTCH)

2



BATTERY
[TA15224](#) (WET CHARGED BATTERY)
[TY26498B](#)

3



ALTERNATOR
[LVA12467](#) (55 A)

4



BELT DRIVE
[M805011](#) (WATER PUMP & THERMOSTAT)
[LVU21854](#) (BELT IDLERS AND COVERS 60 INCH)
[M163989](#) (BELT IDLERS AND COVERS 54 INCH)
[TCU16122](#) (BLOWER HOUSING 60 HC)

5

CAB



SEAT
[LVA22544](#) (OOS)
[LVA22545](#) (CAB)

6

AXLE



TIE ROD
[MIA881641](#) (TIE ROD ASSEMBLY)

7