

# REPLACEMENT PARTS GUIDE

## L118 Lawn Tractor with 42 inch Deck

### ENGINE

#### SPARK PLUG

[M78543](#)

Change Every 50/100/150/200/250 Hrs.

#### ENGINE OIL FILTER

[AM125424](#)

#### ENGINE OIL

[TY22029](#) (TURF GARD™ 10W30)  
(1.8 L (1.9 qt) (WITHOUT FILTER))  
(1.9 L (2 qt) (WITH FILTER))

Change Every 50/100/150/200/250 Hrs.

#### HEADLIGHT BULB

[AD2062R](#)

#### FUEL FILTER-IN-LINE

[AM116304](#)

Change Every 50/100/150/200/250 Hrs.

#### AIR FILTER

[GY20575](#)

Change Every 50/100/150/200/250 Hrs.

#### HOME MAINTENANCE KIT

[LG253](#) (FOR CANADA AND USA)

[AUC17075](#) (NOT FOR CANADA AND USA)

#### MULTI-PURPOSE SD POLYUREA GREASE

[TY6341](#)

Change Interval: As needed.

#### GREASE GUN

[TY26183](#)

### MOWER DECK

#### MOWER BLADE MULCH

[GX20433](#) (HIGH LIFT)

#### MOWER DECK LEVELLING GAUGE

[AM130907](#)

### FUEL AND AIR

#### FUEL TANK FILLER CAP

[GX22166](#)

#### MUFFLER

[GY21132](#)

### ELECTRICAL

#### ROTARY SWITCH

[GY20074](#)

#### PLUNGER SWITCH

[GY20094](#)

#### REVERSE IMPLEMENT PUSH SWITCH

[AM124734](#)

#### TRACTION DRIVE BELT

[UC30568](#) (LGTH = 2258 mm, TK = 9.1 mm,  
WIDTH = 12.45 mm)

#### KEY

[GY20680](#)

#### BATTERY

[TY25221B](#)

#### CONTROL LEVER THROTTLE CABLE

[GY20097](#)

### MOWER DECK

#### GAGE WHEEL

[GX10168](#)

#### FLAT MOWER BELT

[GX20072](#) (LGTH = 2635 mm,  
WIDTH = 12.7 mm, TK = 8.89 mm)

