

REPLACEMENT PARTS GUIDE

1026R Compact Utility Tractor (MY18-) (PIN:1LV1026RAHJ200001-) (Europe Edition)

ENGINE



OIL FILTER

[M806418](#)

Change every 200 hrs and annually.



ENGINE OIL

[TY26669](#) (10W-30 PLUS-50™ II) (2.7 L (2.9 qt))
(WITH FILTER)

Change every 200 hrs and annually.



PRIMARY AIR FILTER

[M113621](#) (HJ200001-JJ202258)

[LVU34503](#) (JJ202259-)

Change every 200 hrs and annually.



SECONDARY AIR FILTER

[M123378](#) (HJ200001-JJ202258)

[LVU34504](#) (JJ202259-)

Change every 200 hrs and annually.



INLINE FUEL FILTER

[AM116304](#)



FUEL FILTER

[MIU804763](#)

Change every 400 hrs and annually.



CAB AIR FILTER

[HF235742801](#)

Change every 50 hrs



JOHN DEERE MULTI PURPOSE HD LITHIUM COMPLEX GREASE

[TY24416](#)

GREASE GUN

[TY26183](#)

Change As Required.



ELECTRICAL



HEAD LIGHT- BULB

[57M7166](#) (12 V, 60/55 W)



BATTERY

[TY26498B](#) (12 V)



V BELT

[M805011](#) (LGTH = 927 mm, WATER PUMP)



KEY

[TA28443](#)



IGNITION SWITCH

[LVU29433](#) (14 V)

FUEL & AIR



FILLER CAP

[AL213202](#)

TRANSMISSION



OIL FILTER

[LVA16054](#) (HYDRAULIC)

Change every 200 hrs.



TRANSMISSION OIL

[TY22000](#) (Low Viscosity Hy-Gard™)
(12.3 L (3.25 gal))

Change every 200 hrs.

AXLE



FRONT AXLE OIL

[TY22035](#) (Low Viscosity Hy-Gard™)
(2.8 L (3.0 qt))

Change every 200 hrs.



TIE ROD

[MIA881641](#)



JOHN DEERE

Genuine Parts and Service

CLICK PART NUMBER TO BUY

*See operator's manual for additional details.