

# REPLACEMENT PARTS GUIDE

## 2026R Compact Utility Tractor (MY17- )(1LV2026RTHH20003- )(Europe Edition)

### ENGINE

#### ENGINE OIL



**TY26669** (10W-30 PLUS-50™ II) (2.7 L (2.9 qt) (WITH FILTER) (CRANKCASE WITH FILTER)

Change Every 200 Hrs or Annually, whichever comes first.

#### FUEL FILTER



**AM116304**

Change after every 400 Hrs/Annually.

#### PRIMARY AIR FILTER



**M113621** (S/N: HH200003 - JJ200380)

**LVU34503** (S/N: JJ200381- )

#### SECONDARY AIR FILTER



**M123378** (S/N: HH200003 - JJ200380)

**LVU34504** (S/N: JJ200381- )

Change every 600/1200 hours.

#### JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE



**TY24416**

#### GREASE GUN

**TY26183**

Change As Required.

#### OIL FILTER



**M806418**

Change every 200 hours/ Annually (whichever comes first)

#### FUEL ELEMENT



**MIA884997** (FUEL FILTER ASSEMBLY)

**MIU804763** (FILTER ELEMENT)

Change every 400 hours/ Annually (whichever comes first)

#### FILTER PAK



**TA25769**



### ELECTRICAL

**KEY**  
**TA28443**

**IGNITION SWITCH**  
**LVU29433** (14 V)

**BATTERY**  
**TY26498B** (12 V)

**WORK LIGHT (OOS)**  
**AM143579** (12 V) (LED)  
**LVA16474** (12 V) (FLOODLAMP)

**HEADLIGHT**  
**57M7166** (12 V, 60 W)

### FUEL & AIR

**FILLER CAP**  
**AL213202**

### AXLE

**TIE ROD**  
**MIA881641** (ASSEMBLY)

**FRONT AXLE OIL**  
**TY22035** (John Deere Low Viscosity Hy-Gard™) (2.8 L (3.0 qt))  
Change every 600 hours/ Annually (whichever comes first)

### TRANSMISSION/ HYDRAULIC

**TRANSMISSION/HYDRAULIC OIL**  
**TY22000** (John Deere Low Viscosity Hy-Gard™) (14.4 L (3.8 gal))

Change every 200 hours/ Annually (whichever comes first)

**OIL FILTER**  
**LVA16054** (HYDRAULIC)

Change every 200 hours/ Annually (whichever comes first)

**V-BELT**  
**M805011** (LGTH = 927 mm)