

# REPLACEMENT PARTS GUIDE

## 2026R Tractor (MY22- ) (PIN: 1LV2026R\*NP100000- ) (Europe Edition)

### ENGINE



**OIL FILTER**  
[M806418](#)

**ENGINE OIL**  
[TY26668](#) (John Deere Plus-50™ II Premium (10W-30)) (2.7 L (2.9 qt)) (With Filter)

Change every 400 hours or annually, whichever comes first.



**PRIMARY AIR FILTER**  
[LVU34503](#)



**SECONDARY AIR FILTER**  
[LVU34504](#)

Change every 600 hours.



**JOHN DEERE MULTI-PURPOSE HD LITHIUM COMPLEX GREASE**  
[TY24416](#)



**PISTOL-GRIP BLACK GREASE GUN**  
[TY26517](#)

Change As Required.



**FUEL FILTER**  
[MIU804763](#) (Fuel Filter Element)



[AM116304](#) (Inline Fuel Filter)

Change every 400 hours or annually, whichever comes first.



**WATER PUMP (V-BELT)**  
[M805011](#) (LGTH = 927 mm)



**FILTER PAK**  
[TA25769](#)



### ELECTRICAL



**COMPACT LED HEADLIGHT**  
[SJ37658](#) (25 W)



**IGNITION KEY**  
[TA28443](#)



**ROTARY SWITCH**  
[LVU29433](#) (14 V)



**WET DISCHARGE BATTERY**  
[TY26498B](#) (12 V, 45 AH, 550 CCA, 22NF BCI)

### FUEL & AIR



**FUEL TANK FILLER CAP**  
[AL213202](#)

### TRANSMISSION/ HYDRAULIC



**HYDRAULIC OIL FILTER**  
[LVA16054](#)

Change every 200 hours.



**TRANSMISSION AND HYDRAULIC OIL**  
[TY22062](#) (John Deere Hy-Gard™)  
[TY22000](#) (John Deere Low Hy-Gard™) (14.4 L (3.8 gal))

Change every 200 hours.

### AXLE



**FRONT AXLE OIL**  
[TY22062](#) (John Deere Hy-Gard™)  
[TY22000](#) (John Deere Low Hy-Gard™) (2.8 L (3.0 qt))

Change every 600 hrs.



**TIE ROD**  
[MIA881641](#) (ASSEMBLY)