

REPLACEMENT PARTS GUIDE

2032R Compact Utility Tractor (MY20-) (PIN: 1LV2032R*LL300001-) (Worldwide Edition)

ENGINE

ENGINE OIL
[TY26669](#) (10W-30 PLUS-50™ II) (4.3 L (4.5 qt))
 (CRANKCASE WITH FILTER)

Change Every 400 Hrs or Annually, whichever comes first.

FUEL FILTER
[MIU800645](#) (PRIMARY)

[MIU803127](#) (SECONDARY)

Change after every 400 Hrs/Annually.

AIR FILTER
[M131802](#) (PRIMARY)

[M131803](#) (SECONDARY)

Change every 600 hrs or annually.

JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE

[TY24416](#)

GREASE GUN

[TY26183](#)

Change As Required.

OIL FILTER

[M806419](#)

Change Every 400 Hrs or Annually, whichever comes first.

FUEL ELEMENT

[AM881823](#) (FUEL & WATER SEPARATOR)

[M811032](#) (FILTER ELEMENT)

Change after every 400 Hrs. or annually.

DIESEL PARTICULATE FILTER

[MIU803093](#)

V-BELT

[LVU30203](#) (LGTH = 995 mm)

FILTER PAK

[LVA23615](#)

ELECTRICAL

KEY

[LVU33004](#)

ROTARY SWITCH

[LVA21501](#) (14 V)

BATTERY

[TY27831B](#) (12 V)

LED WORK LIGHT (OOS)

[LVA16474](#) (12 V)

HEADLIGHT

[57M7166](#) (12 V 60/55 W)

FUEL & AIR

FILLER CAP

[AL213202](#)

AXLE

TIE ROD

[LVA15994](#) (ASSEMBLY)

[LVA15996](#) (RH)

[LVA15995](#) (LH)

FRONT AXLE OIL

[TY22035](#) (John Deere Low Viscosity Hy-Gard™) (3.8 L (4 qt))

Change every 50/400/600 Hrs.

TRANSMISSION/ HYDRAULIC

TRANSMISSION/HYDRAULIC OIL

[TY22035](#) (John Deere Low Viscosity Hy-Gard™) (23.5 L (24.8 qt))

Change after every 400 Hrs or annually.

OIL FILTER

[LVA14703](#) (TRANSMISSION)

[LVA16054](#) (HYDRAULIC)

Change Every 400 Hrs or Annually, whichever comes first.

