

REPLACEMENT PARTS GUIDE

3032E Tractor (MY22-) (PIN: 1LV3032E*NP100000-) (Worldwide Edition)

ENGINE



OIL FILTER
[M806419](#)



ENGINE OIL
[TY26668](#) (John Deere Plus-50™ II Premium (10W-30)) (4.5 L (4.7 qt) - With Filter)

Change every 400 hours or annually, whichever comes first.

1



PRIMARY AIR FILTER
[UC28887](#)



SECONDARY AIR FILTER
[UC28888](#)

Change every 600 hours.

2



DIESEL PARTICULATE FILTER
[MIU803093](#)

3



JOHN DEERE MULTI-PURPOSE HD LITHIUM COMPLEX GREASE
[TY24416](#)



PISTOL-GRIP BLACK GREASE GUN
[TY26517](#)
Change As Required.



FUEL-WATER SEPARATOR
[AM881823](#) (Fuel-water Separatot Kit)

[M811032](#) (Fuel-water Separator Filter Element)

4



FUEL FILTER
[MIU803127](#) (Final Fuel Filter)



[MIU800645](#) (Primary Fuel Filter)

Change every 400 hours or annually, whichever comes first.

5



FAN BELT DRIVE (V-BELT)
[LVU33849](#) (Engine AV13 Section, LGTH = 975 mm)

[LVU30203](#) (Engine AV13 Section, LGTH = 995 mm)

6



FILTER PAK
[TA26997](#)

7

ELECTRICAL



HEAD LIGHT- BULB

[AD2062R](#) (12.8 V, 27 W)

[57M7166](#) (H4 Headlight Bulb, 12 V, 60 W)

7



IGNITION KEY

[LVU33004](#)

8



ROTARY SWITCH

[LVA21501](#) (14 V)

9



WET DISCHARGE BATTERY

[TY27831B](#) (12 V, 45 AH, 550 CCA, 51R BCI)

10

FUEL & AIR



FUEL TANK FILLER CAP

[AL213202](#)

11

TRANSMISSION/ HYDRAULIC



TRANSMISSION OIL FILTER

[LVA14703](#)

Change every 400 hours.

12



HYDRAULIC OIL FILTER

[LVA16054](#)

Change every 400 hours.

13



TRANSMISSION AND HYDRAULIC OIL

[TY22062](#) (John Deere Hy-Gard™)

[TY22000](#) (John Deere Low Hy-Gard™) (20.8 L (5.5 gal))

Change every 1200 hours or 3 years, whichever comes first.

14



14

AXLE



FRONT AXLE OIL

[TY22062](#) (John Deere Hy-Gard™)

[TY22000](#) (John Deere Low Hy-Gard™) (3.8 L (4.0 qt))

Change every 600 hrs.

15



TIE ROD

[LVA15994](#) (ASSEMBLY)

[LVA15995](#) (LH)

[LVA15996](#) (RH)

16

