

REPLACEMENT PARTS GUIDE

3038E Compact Utility Tractor (MY18-) (1LV3038E*HJ120004-)(Worldwide Edition)

ENGINE



OIL FILTER
[M806419](#)



ENGINE OIL
[TY26668](#) (John Deere Plus-50™ II Premium (4.3 L (4.5 qt)) (With Filter)

Change every 200 hours or Annually, whichever comes first



PRIMARY AIR FILTER
[M131802](#)



SECONDARY AIR FILTER
[M131803](#)

Change every 600 hours.



DIESEL PARTICULATE FILTER
[MIU803276](#)



JOHN DEERE MULTI-PURPOSE HD LITHIUM COMPLEX GREASE
[TY24416](#)



PISTOL-GRIP BLACK GREASE GUN
[TY26517](#)

Change As Required.



FUEL-WATER SEPARATOR
[AM881823](#) (Fuel-water Separatot Kit)
[M811032](#) (Fuel-water Separator Filter Element)



FUEL FILTER
[MIU803127](#) (Final Fuel Filter)
[MIU800645](#) (Primary Fuel Filter)

Change every 400 hours or annually, whichever comes first.



FAN BELT DRIVE (V-BELT)
[LVU33849](#) (Engine AV13 Section, LGTH = 975 mm)
[LVU30203](#) (Engine AV13 Section, LGTH = 995 mm)



FILTER PAK
[LVA21037](#)



ELECTRICAL



HEAD LIGHT- BULB
[AD2062R](#) (12.8 V, 27 W)
[57M7166](#) (H4 Headlight Bulb, 12 V, 60 W)



IGNITION KEY
[LVU33004](#)



ROTARY SWITCH
[LVA21501](#) (14 V)



WET DISCHARGE BATTERY
[TY27831B](#) (12 V, 45 AH, 550 CCA, 51R BCI)

FUEL & AIR



MUFFLER
[LVA21057](#)



FUEL TANK FILLER CAP
[AL213202](#)

TRANSMISSION/ HYDRAULIC



TRANSMISSION OIL FILTER
[LVA14703](#)

Change every 400 hours.



HYDRAULIC OIL FILTER
[LVA16054](#)

Change every 400 hours.



TRANSMISSION AND HYDRAULIC OIL
[TY22062](#) (John Deere Hy-Gard™)
[TY22000](#) (John Deere Low Hy-Gard™) (20.8 L (22 qt))

Change every 400 hours.

AXLE



FRONT AXLE OIL
[TY22062](#) (John Deere Hy-Gard™)
[TY22000](#) (John Deere Low Hy-Gard™) (3.8 L (4.0 qt))

Change every 600 hrs.



TIE ROD
[LVA15994](#) (ASSEMBLY)
[LVA15995](#) (LH)
[LVA15996](#) (RH)



CLICK PART NUMBER TO BUY

*See operator's manual for additional details.