

REPLACEMENT PARTS GUIDE

3039R Compact Utility Tractor (1LV3039R*HJ100001-)

ENGINE

ENGINE OIL

TY26668 (John Deere PLUS-50™ II 10W-30)
(4.3 L (1.1 gal))

Change after every 200 hours or annually, whichever comes first.



FINAL FUEL FILTER

MIU803127

Change after every 400 hours or annually.



AIR FILTER

RE68048 (PRIMARY)

RE68049 (SECONDARY)

Change after every 600 hours or annually.



JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE

TY6341

TY26183

Change As Required.



ENGINE OIL FILTER

M806419

Change after every 200 hours or annually, whichever comes first.



FUEL-WATER SEPARATOR

MIU803221 (SEPARATOR)

MIU802421 (FILTER ELEMENT)

Change after every 400 hours or annually.



DIESEL PARTICULATE FILTER

MIA885302



HOME MAINTENANCE KIT

TA25768



AXLE

TIE ROD

LVA19527 (ASSEMBLY)

LVA14960 (LH)

LVA14959 (RH)



FRONT AXLE OIL

TY22000 (John Deere Low Viscosity Hy-Gard™)
(4.8 L (1.3 gal))

Change after every 600 hours.



ELECTRICAL

IGNITION KEY

RE183935



ROTARY SWITCH

LVA21501



BATTERY

TY27831B (12 V, 45 AH, 550 CCA, 51R BCI)



LED WORK LIGHT, OOS

AM143579 (12 V)



HEADLIGHT

R136239 (12.8 V, 50 W)



FUEL & AIR

FUEL TANK FILLER CAP

AL213202



CAB (IF EQUIPPED)

CAB FRESH AIR FILTER

MIU10010

Clean or replace after every 50 hours and as required.



CAB RECIRCULATION AIR FILTER

MIU10011

Clean or replace after every 50 hours and as required.



TRANSMISSION/ HYDRAULIC

TRANSMISSION/HYDRAULIC OIL

TY22000 (John Deere Low Viscosity Hy-Gard™) (25.7 L (6.8 gal))

Change after every 400 hours or annually.



OIL FILTER

LVA13065 (TRANSMISSION) (HH100001 -)

Change after every 400 hours or annually.



V - BELT

LUVU29376 (LGTH = 1112 mm,
WIDTH = 13.4 mm, TK = 9.6 mm)



JOHN DEERE
Genuine Parts and Service

CLICK PART NUMBER TO BUY

*See operator's manual for additional details.